
Table setting


Written By: Mousta Impressoras 3D



Step 1 — Accessing the menu









- With the machine, access the Quick Settings Menu.
- Select the "Leveling Table" option.
- Select "Home XYZ" for the head go to the starting position.


Step 2 — adjustment positions







- The leveling should be performed in 4 points of the table, as shown.
- Select "Adjust P1" to level the table height at the first point.

Step 3 — Adjusting the table height








- The nozzle should be slightly away from the glass (thickness of a sheet sulfite).
- To approach the nozzle table, turn the rosette clockwise.
- To ward off the nozzle table, turn the rosette in a counterclockwise direction.

Step 4 — Setting the other points







- Repeat P1 adjustment procedure for the other points.

Pronto! Sua mesa está nivelada!

This document was last generated on 2017-07-27 11:10:13 AM.

